



High-Volume Kit (Sold separately)

Make up to 1000 injections without reloading chemical. Simply attach the hose to the Wedgle Direct-Inject unit** and the 1000 ml chemical pack,** prime, and inject. No other tools, equipment, or power supply are needed.

1. Remove the yellow cap from the hose guide by unscrewing. Remove the adaptor sleeve from inside the hose guide.
2. Slide the High-Volume hose through the yellow cap and into the hose guide, pulling the hose through the chemical pack cage and out the top of the backpack.



3. Attach the hose to a 1000 ml chemical pack** using the same method as you attach a 120 ml chemical pack to the injection unit (see instruction on page 2).

4. Carefully pull the hose and chemical pack into the cage inside the backpack until the chemical pack rest snugly against the hose guide.
5. Secure the chemical pack in the cage with the closure pin.
6. Place the adaptor sleeve over the hose and slide the sleeve into the hose guide.
7. Screw the yellow cap onto the hose guide and hand tighten.
8. Attach the hose to the top QC coupler on the injection unit.
9. Prime and you are ready to begin injecting.

NOTES: When priming or using the high-volume kit, the chemical pack should always be at or above the injector.

The high-volume hose contains approximately 30ml of chemical when primed. Priming the hose will take 30 or more pumps of the injector to fill.

‡Product may differ from actual product. **Sold separately

