

## E-Z ACCESS® II INSTALLATION INSTRUCTIONS

1. Cut rough opening using chart below.
2. Apply adhesive to frame.
3. Insert door in frame, position panel in bottom of rough opening.
4. Adjust panel slightly upwards until bottom of door rests against bottom of frame.

Description	Door Size		O.D. Size		Cut Out Size	
	W	H	W	H	W	H
5"x5" Access Panel	5"	5.25"	7.75"	8"	5.25"	6"
6"x9" Access Panel	9.75"	6.75"	12.5"	9.5"	10.25"	7.5"
8"x8" Access Panel	9"	9"	11.75"	11.75"	9.25"	9.75"
12"x12" Access Panel	12"	12"	14.75"	14.75"	12.5"	12.75"
16"x16" Access Panel	14"	14"	16.75"	16.75"	14.5"	14.75"

\* Door should not be installed near any existing/potential heat source or open flame.  
As with any building product you should consult local building/fire codes.