


Sub-Slab Injector (SSI-4, SSI-14)

#	Part	Description
1	VT-610	Valve assembly
2	VT-618	Rod spring
3	I-1964	O-Ring
4	2673	Valve rod
5	VT-611	Valve trigger
6	VT-609	Trigger pin
7	TN-45	Hex nut
8	1138	Spacer
9	VT-612	Rod screw
10	VT-615	Trigger lock
11	VT-616	Trigger spring
12	VT-617	Trigger screw
13	22065300	Wing nut
14	2674	Extension rod for #4
	2675	Extension rod for #14
15	2668	Shaft for #4
	2669	Shaft for #14
16	400	Lock sleeve for #4
	500	Lock sleeve for #14
17	SSL-157	Seat stem lock nut
18	2676	Seat stem
19	2677	Seat gasket
20	2678	Stud
21	#5	Compression ring
22	#6	Expansion ring
23	1370	Tip adapter
24	LDT-36	Extension, 6 in.
25	1390	360°, 2 gpm
26	1542	180° fan, 2 gpm



MISCELLANEOUS REPAIR KITS

39

OFFICE EMERGENCY KIT OE-126 (Order # 23088126)

1	PV-266	22027200	Check valve
1	P-268	22028000	Tank gasket
1	5053	22032500	Strainer assembly
1	NP-270	22028600	Spreader front plate
1	NP-277	22029000	Plastic plunger cup
1	P-276	22029900	Lock spring
1	D-51-P	22030400	Washer (hose coupling)
1	4190	22034700	Gasket (Viton)
1	-----	24010026	Adjust.-tip gasket
1	-----	24010002	O-ring, Viton size 117
1	OR-5942	22035500	O-ring
1	OR-5943	22035800	O-ring
1	1-1935	33000022	O-ring (Viton)
1	1-1964	33000090	O-ring (Viton)
1	NG-146	22044200	Gasket (Nylon)
1	4143	22039100	Gasket, copper
1	VP-151	22045099	Valve packing
1	MS-145-50	22043800	Mesh screen
1	-----	20002010	Foam screen
1	SGH-50	22041500	Seat gasket holder
1	VP-151	22045099	Valve packing
1	SP-159	22046300	Soft seat gasket
1	DR-020	22056600	Gland pump
1	MDR-8	22058100	Seal
1	VT-621A	22060000	Valve seat gasket
1	VT-622A	22060100	Seat gasket holder
1	#6	22065800	Keroseal ring
1	1282	22071182	Seat gasket
1	ACS-26	22071715	Cone seal 7/16
1	ACS-25	22071771	Cone seal 1/2
1	2677	22071977	Gasket seat
1	HA-298	22025300	Hose adapter 1/8
1	SF-5944	22036000	Seat follower
1	S-5945	22036200	Spring
1	-----	22037502	XR-Gun Trigger
1	4817	22037800	Valve stem sub-assembly

Rev 9/06