




Stainless Steel Sprayer

#	Part	Description	#	Part	Description
1	T-50	Tank, ½ gallon	8	P-275	Pump handle
	T-100	Tank, 1 gallon	9	P-276	Pump lock spring
	T-200	Tank, 2 gallon	10	P-274	Pump cap
	T-300	Tank, 3 gallon	11	PH-273	Plunger rod, ½ gal.
	T-500	Tank, 5 liter		PO-273	Plunger rod, 1 gal.
2	HS-297	Siphon tube, ½ gal.		PF-265	Plunger rod, 2 gal., 5 L
	OS-297	Siphon tube, 1 gal.		PT-265	Plunger rod, 3 gal.
	TS-297	Siphon tube, 2 gal.	12	P-272	Back plate
	THS-297-01	Siphon tube, 3 gal.	13	NP-277	Polypropylene cup
	FS-297	Siphon tube, 5 liter	14	NP-270	Cup spreader plate
3	HA-298	Adapter, hose	15	P-269A	Lock washer
4A	TT-1	Tank top (1 gal.)	16	P-269-SS	Plunger nut
4D	TB-1	Tank bottom	17	P-268	Pump gasket
5	5700-H	Tip holder	18	PH-267	Pump tube, ½ gal.
6	D-50	Hose, 4 ft. red		PO-267	Pump tube, 1 gal.
7	D-51-P	Hose washer		PF-267	Pump tube, 2 gal.
				PT-267	Pump tube, 3 gal.
			19	PV-266	Check valve