

Sub-Slab Injector (SSI-4, SSI-14)

#	Part	Description
1	VT-610	Valve assembly
2	VT-618	Rod spring
3	I-1964	O-Ring
4	2673	Valve rod
5	VT-611	Valve trigger
6	VT-609	Trigger pin
7	TN-45	Hex nut
8	1138	Spacer
9	VT-612	Rod screw
10	VT-615	Trigger lock
11	VT-616	Trigger spring
12	VT-617	Trigger screw
13	22065300	Wing nut
14	2674	Extension rod for #4
	2675	Extension rod for #14
15	2668	Shaft for #4
	2669	Shaft for #14
16	400	Lock sleeve for #4
	500	Lock sleeve for #14
17	SSL-157	Seat stem lock nut
18	2676	Seat stem
19	2677	Seat gasket
20	2678	Stud
21	#5	Compression ring
22	#6	Expansion ring
23	1370	Tip adapter
24	LDT-36	Extension, 6 in.
25	1390	360°, 2 gpm
26	1542	180° fan, 2 gpm

