

BioStim, LLC PO Box 1737 Boerne, TX 78006 Phone (800) 338-8812 Fax (830) 336-4827 www.biostim.com

KB-VF INJECTION FORMULA

For use in food service facility three-compartment sink drain lines, and other appropriate drain lines. Delivered via an automatic injection pump to provide consistent treatment of drain lines. May be used in conjunction with *Fast Food / X-ray Formula* and *BioPill*.



Application Instructions:

Remove pump from 5 gallon bucket if already attached. Clean bucket with water ONLY before adding new bacteria. Mix with 5 gallons of water in bucket. Reattach pump to bucket. Follow manufacture instruction for pump. Use all of the mixture at time of service. Repeat monthly.

Storage:

Store at ambient temperature; do not allow to freeze.

Product Information:

Environmentally friendly Safe for plumbing lines and septic systems Contains no corrosive or caustic chemicals No free enzymes or FOG emulsifiers Non-flammable
Does not cause pass-through
Multiple strains of naturally occurring bacteria

Precautions:

Do not ingest
Keep out of reach of children
Avoid contact with open wounds
People with autoimmune deficiencies should avoid contact

Do not inhale Wear latex gloves for hygiene Avoid contact with eyes, nose, or mouth Wash hands with soap and water after handling

First Aid:

In case of contact with <u>eyes</u>: flush with water for 15 minutes; seek medical attention if irritation persists. In case of contact with <u>skin</u>: wash with soap and water; remove contaminated clothing. In case of <u>inhalation</u>: remove victim to fresh air if trouble breathing; seek medical attention immediately. In case of <u>ingestion</u>: drink water to dilute; do NOT induce vomiting; seek medical attention immediately.

MSDS available at www.biostim.com under "Products" tab.

