

Large Tree Micro-infusion™

600mL is the maximum fill capacity.

If more than 600mL is used, the TREE I.V. requires RE-PRESSURIZING during Micro-infusion.

More than 1 TREE I.V. can be used on the same tree.

Examples:

- If dose is 1000mL, put 500mL in 2 TREE I.V. bottles.
- If dose is 1350mL, put 450mL in 3 TREE I.V. bottles.



Or Use the Expansion Kit: 010-7016
This includes the Expansion Manifold, 4 VIPER Valve Assemblies, and 5/32" 4-line Manifold.

This allows you to have 8, 12, or 16 injection sites per tree with only 1 TREE I.V. bottle.



Expansion Manifold connects to bottle top



Additional 4 line manifold(s) are connected